

HEX HEAD CAP SCREW - COARSE THREAD  
GRADE 5 ZINC



1/4-20	5/16-18	3/8-16	7/16-14	1/2-13	9/16-12	5/8-11	3/4-10	7/8-9
1/2	1/2	1/2	3/4	3/4	1"	1"	1"	1 1/2
5/8	5/8	5/8	7/8	7/8	1 1/4	1 1/4	1 1/4	1 3/4
3/4	3/4	3/4	1"	1"	1 1/2	1 1/2	1 1/2	2"
7/8	7/8	7/8	1 1/4	1 1/4	1 3/4	1 3/4	1 3/4	2 1/4
1"	1"	1"	1 1/2	1 1/2	2"	2"	2"	2 1/2
1 1/4	1 1/4	1 1/4	1 3/4	1 3/4	2 1/4	2 1/4	2 1/4	2 3/4
1 1/2	1 1/2	1 1/2	2"	2"	2 1/2	2 1/2	2 1/2	3"
1 3/4	1 3/4	1 3/4	2 1/4	2 1/4	2 3/4	2 3/4	2 3/4	3 1/4
2"	2"	2"	2 1/2	2 1/2	3"	3"	3"	3 1/2
2 1/4	2 1/4	2 1/4	2 3/4	2 3/4	3 1/4	3 1/4	3 1/4	3 3/4
2 1/2	2 1/2	2 1/2	3"	3"	3 1/2	3 1/2	3 1/2	4"
2 3/4	2 3/4	2 3/4	3 1/4	3 1/4	3 3/4	3 3/4	3 3/4	4 1/2
3"	3"	3"	3 1/2	3 1/2	4"	4"	4"	5"
3 1/4	3 1/4	3 1/4	3 3/4	3 3/4	4 1/2	4 1/2	4 1/2	5 1/2
3 1/2	3 1/2	3 1/2	4"	4"	5"	5"	5"	6"
3 3/4	3 3/4	3 3/4	4 1/2	4 1/2	5 1/2	5 1/2	5 1/2	6 1/2
4"	4"	4"	5"	5"	6"	6"	6"	7"
4 1/2	4 1/2	4 1/2	5 1/2	5 1/2	7"	6 1/2	6 1/2	7 1/2
5"	5"	5"	6"	6"		7"	7"	8"
5 1/2	5 1/2	5 1/2	8"	6 1/2		7 1/2	7 1/2	8 1/2
6"	6"	6"		7"		8"	8"	9"
	7"	6 1/2		7 1/2		8 1/2	8 1/2	9 1/2
		7"		8"		9"	9"	10"
		7 1/2		8 1/2		10"	9 1/2	11"
		8"		9"		11"	10"	
				9 1/2			14"	
				10"				
				11"				

HEX HEAD CAP SCREW - COARSE THREAD  
GRADE 5 ZINC



1"-8	1 1/8-7	1 1/4-7	1 1/2-6
1 1/2	2 1/2	2"	4 1/2
1 3/4	2 3/4	2 1/4	7"
2"	3"	2 1/2	7 1/2
2 1/4	3 1/2	3"	8"
2 1/2	3 3/4	3 1/4	9"
2 3/4	4"	3 1/2	
3"	4 1/2	4"	
3 1/4	5"	4 1/2	
3 1/2	5 1/2	5"	
3 3/4	6"	5 1/2	
4"	6 1/2	6"	
4 1/2	7 1/2	6 1/2	
5"	8"	7"	
5 1/2	8 1/2	7 1/2	
6"	9"	8 1/2	
7"	10"	9"	
7 1/2		10"	
8"			
8 1/2			
9"			
9 1/2			
10"			